

Taking The Wheel Profile (ID Procedure)

1. Use a contour gage to profile the wheel.



2. Place the contour gage on the wheel perpendicular to the surface and position the comb against the wheel profile.



3. Remove the contour gage from the wheel and trace the profile on a sheet of paper. Trace the contour gage as accurate as possible. Place an 2" x-y scale on the sheet so we can resize the form due to fax compression.



4. Send the original profile sheet to:
Joe Duffy
Rodgard
716-852-7690 fax or jduffy@rodgard.com